OPERATING INSTRUCTIONS:
Coin Operated Dryer

- Clean lint screen before each use
- Sort and load clothes
- Close door
- Select DRYING Cycle
- Insert coins and push coinslide in
- Press "START" button